

Decontamination tent PZ 40 3 L



- Ready to use in only 5 minutes
- Optimised room layout
- For up to 12 persons at a time
- Also for injured persons in horizontal position



www.vetter.de/vetter_emergency/en/Rescue+Products/Pneumatic+tents+and+showers/Decontamination+tent+PZ+40+3+L.html

Safe and quick mass decontamination.

Every minute counts in an emergency. Decontaminate large numbers of people in a short time. With two longitudinal separation walls, the tent can be divided into 3 decontamination lines. Use the middle line (1.85 m / 5.93 ft. wide) for decontamination of injured persons in horizontal position, the two outer lines (1.62 m / 5.18 ft. wide) offer enough space for separate showering of men and women.

The shower units divide the tent into areas for undressing, showering and dressing. Since every shower unit has its own water supply, the quantity and temperature of water can be controlled individually. The colour coding of the duct openings in the tent provides practical orientation (blue: water, red: heating or electricity, green: compressed air).

A one- piece collection tub in the shower area prevents liquids from pouring into the tent. To extend the functionality of the PZ 40 3 L, you can easily connect PZ 30 and PZ 40 universal tents and use them as additional supply or accommodation units.

Standard components

The PZ 40 3 L decontamination tent includes as standard components:

- Inflatable tent frame with tensioning ropes
- Detachable cover with detachable entry awnings
- 6 doors (3 in each entry awning)
- 6 windows (3 in each entry awning)
- Detachable floor
- 2 detachable longitudinal separation walls for dividing the tent into the 3 lines
- 3 shower units with removable shower curtains and shower hoses
- Shower basin of polyester fabric with PVC coating on both sides (other qualities on request)
- 12 hand showers (4 per shower unit)

Each tent includes an accessory bag with hammer, pegs and repair material. All of the equipment is delivered in a handy package. An expandable roller conveyer with spineboards is optionally available.

Tent colours



The Vetter standard colours

You want another colour?

No problem, just call us on: +49 (0)2252 / 3008-60

Emergency Pneumatics

Technical data

- Working pressure: 0.5 bar (7.25 psi)
- Test pressure: 0.65 bar (9.4 psi)

Product	Art. no.	Setup time, approx. sec / <i>sec</i>	Ext. dimensions (L x W x H) m / <i>ft.</i>	Int. dimensions (L x W x H) m / <i>ft.</i>	Air requirement, at working pressure litres / <i>cu.ft.</i>	Folded size (L x W x H) m / <i>inch</i>	Weight, approx. kg / <i>lbs</i>	Collection tub litres / <i>cu.ft.</i>
PZ 40 3 L	1520035500	300 <i>300</i>	8 x 5,5 x 3,1 <i>25,6 x 17,6 x 9,9</i>	8 x 5,1 x 2,9 <i>25,6 x 16,3 x 9,3</i>	6863,0 <i>242,3</i>	1,1 x 0,85 x 0,85 42,9 x 33,2 x 33,2	204,0 <i>450,0</i>	2610 <i>92,1</i>

Accessories

- Inflation with cylinder
- Inflation with blower
- Deflation
- Equipment
- Lighting
- Climate control
- Water supply



In operation...

- Epidemics
- Decontamination of patients in front of hospitals
- ABC protection measures after industrial and reactor accidents
- Terror attacks or events of war



Good reasons...

- Saves time and personnel
- Only one inflation connection for the entire system
- Inflation with compressed air cylinder or blower
- Detachable components for easy cleaning
- Connectable with universal tents PZ 30 or PZ 40



Guaranteed quality:

- Individually tested (with inspection seal)
- Integrated safety valve prevents overinflation
- Support frame of sturdy material

Please contact us directly should you have any further questions concerning this product.

Sales Germany
Phone.: +49 (0) 22 52 / 30 08-50
Fax: +49 (0) 22 52 / 30 08-70
E- Mail: vetter.info@idexcorp.com

Sales international
Phone.: +49 (0) 22 52 / 30 08-60
Fax: +49 (0) 22 52 / 30 08-71
E- Mail: vetter.info@idexcorp.com

Or find the nearest dealer under:
[www.vetter.de/ support/ haendler](http://www.vetter.de/support/haendler)
